

ES5000 400V 50Hz

#### LONG RUN ENERGY



A petrol generator designed specifically for intensive operations where performance power is demanded by professional user, over an extended period of time.

#### **Standard Equipment**

Starting system Recoil

Main Features		
Frequency	Hz	50
Voltage	V	400
Power factor	cos φ	0.8
Single Phase Power factor	cos φ	0.9
Phase and connection		3

Power Rating		
Standby power LTP	kVA	6.3
Standby power LTP	kW	5.0
Continuous power COP	kVA	5.4
Continuous power COP	kW	4.3

Single Phase Power Rating		
Single phase standby power LTP	kVA	3.8
Single phase continuous power COP	kVA	3.5

### Ratings definition (According to standard ISO8528 1:2005)

**COP** - Continuous Power:

It is defined as being the maximum power which a generating set is capable of delivering continuously for an unlimited number of hours, with the maintenance intervals and procedures being carried out as prescribed by the manufacturers.

### **LTP** - Limited-Time running Power:

It is defined as the maximum power available, under the agreed operating conditions, for which the generating set is capable of delivering for up to 500 h of operation per year (whose no more than 300 for continuative use) with the maintenance intervals and procedures being carried out as prescribed by the manufacturers. No overload capability is available.



ES5000 400V 50Hz

## **Engine Specifications**

Brand		Honda
Model		GX270 Recoil
Engine cooling system		Air
Displacement	cm³	270
Aspiration		Natural
Speed governor		Mechanical
Operating Speed-Nominal	rpm	3000
Oil capacity	L	1.1
Fuel		Gasoline
Starting system		Recoil
Fuel consumption @ 75% PRP	L/h	1.66



## **Alternator Specifications**

Class		Н
IP protection		23
Poles		2
Voltage tolerance	%	6

## Dimensional data

Length	(L) mm	729
Width	(W) mm	500
Height	(H) mm	536
Dry weight	kg	61
Fuel tank capacity	L	11

## Autonomy

Running time @ 75% PRP h 6.63

## Noise level

Guaranteed noise level (LWA)	db(A)	97
Noise pressure level @ 7 mt	db(A)	69



ES5000 400V 50Hz

### **GENSET CONTROL**

#### **COMMANDS:**

- Selector switch: OFF - ON - Starting systems: Recoil


- Fuel Cock

#### **PROTECTIONS STANDARD:**

- Thermal protection

- Oil Guard

#### **SOCKET TYPE**







ES5000 400V 50Hz

### **ACCESSORIES**

#### TRANSPORTATION KIT

- With fix handles
- With folding handles





